

08/942, 005





FIG. 1

FIG. 2



08/942, 125




FIG. 3




FIG. 4A




FIG. 5

08/942,015




FIG. 6




FIG. 7




FIG. 8




FIG. 9

1000 — ALERT MANAGER MODULE 202 — 1002 — 1004

ALERT MANAGER TABLE

SERVER 1 (NAME)

CPU ALERT DESCRIPTION: "CPU IDENTIFIED BY THE CPU NUMBER FAILED BECAUSE OF HIGH TEMPERATURE AND/OR LOW POWER"

NOTIFY YES/NO

SYSTEM BOARD FAN ALERT

NOTIFY YES/NO

TEMPERATURE SENSOR ALERT

NOTIFY YES/NO

POWER SUPPLY ALERT

NOTIFY YES/NO

ADAPTER ALERT

NOTIFY YES/NO

CANISTER ALERT

NOTIFY _____

SLOT FAN ALERT

NOTIFY _____

CANISTER FAN ALERT

NOTIFY _____

SERVER 2 (NAME)

CPU ALERT

NOTIFY YES/NO

•

•

•

(TYPICAL METHODS)

CALL ALERT MANAGER DIALOG MODULE 216

CALL ALERT FLASH DIALOG MODULE 218

1006

FIG. 10




FIG. 11




FIG. 12